


Mounting instruction


Montagevejledning

Montageanleitung

Active Load
220-240V ~ 50Hz



[GB] Leadwire must only be replaced by the manufacturer.
[DK] Tilledningen må kun udskiftes af fabrikanten.
[D] Der Kabel muss nur vom Hersteller ersetzt werden.



[GB] Connecting Active Load.
[DK] Tilslutning af Active Load.
[D] Verbindung von Active Load.

